

When replacing a driving cord, it should be noted that a simple reef knot is the most effective joint. The cord should be placed about the wheel and over the whorl, then pulled approximately two inches too short and knotted. After replacing on the wheel and whorl, the belt should be gently stretched and the tension adjusted and set.

It should be remembered that this light fishing line for the wheel costs about three cents, and a replacement time of about one minute.

To preserve the rich appearance of the wheel, it is recommended that grease and oil be removed with a damp, soapy cloth before polishing with a recognised quality furniture polish.

Your NAGY spinning wheel has been crafted with much pleasure and extreme care — use of it in a similar manner will provide a lifetime of service and joy.

Every NAGY spinning wheel is guaranteed against faulty materials and workmanship for the lifetime of the maker. Should your wheel not perform to perfection, please contact the maker who will consider any assistance a happy obligation.

THE LOVING CARE OF YOUR SPINNING EQUIPMENT IS PART  
OF YOUR SPINNING.



How to look after your  
"NAGY" Spinning Wheel  
with loving care

Postal Address:  
P.O. Box 9637,  
Wellington,  
New Zealand.

Factory:  
107 Daniell Street,  
Newtown,  
Wellington.

Phone: 899-350